








WuWu

KOMODA 4SZ






P






P1








P2

























3x **10**



















PL: W celu ustabilizowana mebla występuje konieczność przykręcenia do ściany!!!
 ANG: To ensure the stability of the furniture, it must be screwed to the wall !!!
 DE: Zur Stabilisierung des Möbelstücks muss es an der Wand angeschraubt werden !!!
 FR: Afin de stabiliser le meuble, il est nécessaire de le fixer au mur avec des vis.

